


# Safeguard Your Power Supply

## Protect plugs and outlets




Plug in unit to a nearby outlet.

Secure plug with a guard or cover.

Post “Do Not Unplug” signs near outlet.


## Always avoid disruption of power




Do not use extension cords.




Do not plug more than one appliance into an outlet.




Do not use power strips.



Do not use outlets that are controlled by wall switches.



Never unplug the vaccine refrigerator or freezer.



Label the circuit breaker.

If you experience a power failure, do not open refrigerator or freezer doors; call the NYC VFC program at 347-396-2404.